

# HOME DECORATORS C O L L E C T I O N


BF-25178 MARTHA STEWART LIVING KIDS CRAFT TABLE 31"Hx40"Wx24"D

INV#19038

## ASSEMBLY INSTRUCTIONS

Made In China













THIS ITEM MUST BE ASSEMBLED BY AN ADULT



Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Count all parts and material hardware, then compare with parts list to be sure all parts are present. If any parts are missing or damaged, phone, fax, or mail to our Customer Service Department for efficient and speedy service. Please indicate the model number and code letter of part(s) needed.



**IMPORTANT NOTE:** Follow instructions listed below in proper sequence as numbered to assure fast, easy and correct assembly.

## PARTS LIST


|   |   |  |
|---|---|--|
| <b>A</b><br><br>TOP PANEL-1PC                    | <b>B</b><br><br>LEFT SIDE PANEL-1PC      | <b>C</b><br><br>RIGHT SIDE PANEL-1PC            |
| <b>D</b><br><br>BACK PANEL-1PC                 | <b>E</b><br><br>ADORNING PANEL-1PC     | <b>F</b><br><br>BOTTOM FRAME-1PC              |
| <b>G</b><br><br>PANEL-1PC                      | <b>H</b><br><br>DRAWER PANEL FRONT-1PC | <b>I</b><br><br>LEFT<br>DRAWER PANEL SIDE-1PC |
| <b>J</b><br><br>RIGHT<br>DRAWER PANEL SIDE-1PC | <b>K</b><br><br>DRAWER PANEL BACK-1PC  | <b>L</b><br><br>DRAWER PANEL BOTTOM-1PC       |

**M**


DRAWER STAND PANELS-2PCS

**N**DRAWER  
SUPPORT PANELS-2PCS**O**

DRAWER ACROSS PANELS-2PCS

**P**

OUTER SLIDES-2PCS

**Q**

INNER SLIDES-2PCS

**R**

ALLEN WRENCH-1PC

**S**


KNOBS-2PCS

**T**


8mm × 5/8"



SCREWS-2PCS

**U**


FEET-4PCS

**V**

DOWELS-2PCS

**W**

6mm × 1/2"



SCREWS-12PCS

**X**


8mm × 1"



SCREWS-3PCS

**Y**


6mm × 1"



SCREWS-16PCS

**Z**


11mm × 1"




BOLTS-19PCS

**A1**

8mm × 1-1/2"




SCREWS-2PCS

**B1**

HOOKS-4PCS

**C1**


PLASTIC BELTS-2PCS

**D1**

GECKOS-4PCS

**E1**


6mm × 3/4"



SCREWS-4PCS


**F1**

7mm × 7/8"




SCREWS-4PCS

NOTE: THE SURFACE WITH THE STICKER IS THE BACK SIDE.




1). ASSEMBLE THE OUTER SLIDES (P).

- ATTACH THE OUTER SLIDES (P) TO RIGHT SIDE PANEL (C) USING 3 SCREWS (W).




2). ASSEMBLE THE OUTER SLIDES (P).

- ATTACH THE OUTER SLIDES (P) TO LEFT SIDE PANEL (B) USING 3 SCREWS (W).




3). ASSEMBLE THE BACK PANEL (D).

- ATTACH THE BACK PANEL (D) TO LEFT SIDE PANEL (B) USING 2 BOLTS (Z).




4). ASSEMBLE THE BOTTOM FRAME (F).

- ATTACH THE BOTTOM FRAME (F) TO LEFT SIDE PANEL (B) USING 2 BOLTS (Z).



5). ASSEMBLE THE PANEL (E/F).


- ROTATE 4 BOLTS (Z) INTO THE HOLES IN THE BOTTOM FRAME (F).
- INSERT 1 DOWEL (V) INTO THE HOLE IN THE LEFT SIDE PANEL (B).
- ATTACH THE PANEL (G) TO LEFT SIDE PANEL (B) USING 1 SCREW (A1).



6). ASSEMBLE THE RIGHT SIDE PANEL (C).


- INSERT 1 DOWEL (V) INTO THE HOLES IN THE RIGHT SIDE PANEL (C).
- ATTACH THE BACK PANEL (D) TO RIGHT SIDE PANEL (C) USING 2 BOLTS (Z).
- ATTACH THE PANEL (G) TO RIGHT SIDE PANEL (C) USING 1 SCREW (A1).






7). ASSEMBLE THE BOTTOM FRAME (F).

- ROTATE 2 BOLTS (Z) INTO THE HOLES IN THE BOTTOM FRAME (F).




8). ASSEMBLE THE ADORNING PANEL (E).

- ATTACH THE ADORNING PANEL (E) TO TOP PANEL (A) USING 3 SCREWS (X).




9). ASSEMBLE THE TOP PANEL (A).

- ATTACH THE TOP PANEL (A) TO PANEL (B/C/D) USING 7 SCREWS (Z).



10). ASSEMBLE THE FEET (U).


- ROTATE 4 FEET (U) INTO THE HOLES IN THE SIDE PANEL (B/C).




### 11). ASSEMBLE THE DRAWER.

- ATTACH DRAWER PANEL SIDE(I/J) USING 4 SCREWS(Y).
- ATTACH 2 KNOBS(S) TO DRAWER PANEL FRONT(H) USING 2 SCREWS(T).
- INSERT THE DRAWER PANEL BOTTOM(L) INTO THE SLOTS IN THE DRAWER PANEL SIDE(I/J).
- ATTACH DRAWER PANEL BACK(K) BETWEEN LEFT DRAWER PANEL SIDE(I) AND RIGHT DRAWER PANEL SIDE(J) USING 4 SCREWS(Y).
- ATTACH THE DRAWER SUPPORT PANEL(N) TO DRAWER PANEL BOTTOM(L) USING 8 SCREWS(Y).

Arrow faces drawer front




Arrow faces drawer front



## 12). ASSEMBLE THE INNER SLIDES(Q).

- ATTACH THE INNER SLIDES(Q) TO DRAWER PANEL SIDE(I/J) USING 6 SCREWS(W).
- INSERT PANELS(M/O) INTO THE SLOTS IN THE DRAWER.




13). ASSEMBLE THE DRAWER.

- INSERT THE DRAWER INTO THE SLIDERS.



# Warning

The anti-tip hardware must be used as part of assembly!



14). ASSEMBLE THE HOOKS (B1).

- ATTACH THE HOOKS (B1) TO TOP PANEL (A) USING 4 SCREWS (E1).



### 15). ASSEMBLE THE ANTI-TIP HARDWARE.

- DRILL 4 HOLES INTO THE WALL, PLEASE REFER TO THE REAR TOP PANEN'S HOLE DISTANCE AND HEIGHT.
- PUT 4 GECKOS(D1) INTO THE HOLES IN THE WALL, AND ROTATE 4 SCREWS(F1) INTO THE GECKOS(D1).
- CONNECT THE TWO HOOKS(B1) WITH A PLASTIC BELT(C1).